

The Button Night (HA2000NS)

The Button Night is to be positioned for example on the wall beside your bedside table, allows an activation partial and disarmament of the system since your room to be slept, for a protection your involved. The symbols are phosphorescent so that they can be seen of night.

1/ **RED BUTTON** Support on it button during 1 second to put l' alarms in mode "ARM. Partial".

2/ **GREEN BUTTON** Support on it button during 1 second to put l' alarms in "Disarmed" mode.

- **Indicator**

When is the Rouge button or the Button Green is supported, seeing it TX will flicker to indicate that HA2000NS has correctly sent a signal to the power station.

- **Batterie**

HA2000NS uses an alkaline battery of 12V 35mAh like d' source; energy. battery can be useful for roughly 2,600 transmissions of signals before to change.

HA2000NS can also detect the statu battery. The weak signal of battery will be envoy with the Power station by transmissions regular.

- **To start**

- Withdraw the screw to separate the cap superior of the base.
- Insert the battery with the negative one of with dimensions one spring.
- Replace the cap on the basis.
- Put the power station on small "the Acc. + " then select the menu "To add Acc."
- Support on which button of HA2000NS.
- Support on "OK" on the power station and follow its adjustments to complete it process d' training. You with the handbook d' refer; use of your power station in the section "Acc. + " to complete the process d' training.
- The process d' training is now completed.
- After the HA2000NS is configured, put to the Power station in mode "Test Mode", maintain l' Switch of Night HA2000NS with l' desired place then press on the button to confirm that this place is with range of Power station.
- When the position of operation of HA2000NS is appropriate to you, you can to proceed to its installation.

- **To assemble the HA2000NS**

There are 2 ways of assembling the HA2000NS is by installation with adhesives, that is to say by assembly with screw. Installation with adhesives

1. Clean surface with one suitable grease-remover.
2. Withdraw protective film on with dimensions two-sided adhesive band and apply firmly to the back of l' apparatus.
3. Then withdraw l' another protective film and support firmly on l' object with l' desired place. Assembly with screw The base has two parts where plastic is finer.

- **Assembly with screw**

1. Withdraw the screw to separate the cap superior of the base.
2. bore the finer parts of base.
3. Use the holes as model, bore two holes and insert them ankles. 4. Screw the base in the ankles. 5. Screw the higher cap on low